



Parts included:

1 ea Vent Mount

**Options**

- **(Gemini Magnetic Phone Mount)**

- 1 ea Tibia w/ Ball

- 1 ea Gemini Magnet w/ Adhesive Metal Plate

- 1 ea 1/4-20 Button Head Cap Screw

- 1 ea Nylon Washer

- **(XXL Phone Mount)**

- 1 ea Tibia w/ Universal Scissor Phone Mount

- 1 ea 1/4-20 Button Head Cap Screw

- 1 ea Nylon Washer

- **(FlexPod Gauge Cup)**

- 1 ea FlexPod Gauge Cup (52mm or 60mm)

- 1 ea ABS Gauge Cup Backing Plate

- 2 ea Adhesive-Backed Foam Bumpers

- 1 ea 1/4-20 Cap Head Screw

- 1 ea Nylon Washer

- 1 ea Plastic Cap

Tools Required:

5/32" Allen Key

Thin Metal Blade (table knife or similar)

Small Flat-bladed Screwdriver

## **Disassembly Procedure**

1. Choose which vent you would like to install the mount on. Slip a thin metal bladed tool between the vent trim ring and the surface of the dash. Gently twist the tool to release the trim ring clips. There are four clips located at approx the 1, 4, 7, and 10 o'clock positions.



2. Once you have the trim ring popped off, use a small, flat-bladed screwdriver and release the vent assembly clips from the dash as follows:

- Place the screwdriver just inside the four plastic tabs at an extreme angle and gently pry the inner clips loose. The inner clips need to be pried toward the center of the vent.



**NOTE:** It may be helpful to grasp the center of the vent and gently pull on the assembly as each of the four clips release.



**\*The above images show the required position of the screwdriver in relation to the clips.**



## Assemble and Install Vent Mount

1. Take the CravenSpeed Vent Mount, line up the gap in the ring with the raised, 'rib' section on the outer surface of the vent assembly.



2. Press the two pieces together until the (4) clips of the vent assembly fully engage the groove inside the Vent Mount. You should be able to hear or sense the clips as they set into place.





3. Set the vent trim bezel back onto the vent assembly making sure the (4) mounting clips are lined up properly and press together till the clips all fully engage.



4. With the mounting tab on the Vent Mount oriented straight up, place the assembly back into the receptacle on the dash and with gentle but firm pressure, push the assembly into the dash until it fully seats.



**5. You are now ready to mount your accessory of choice!**



## **Accessory Mounting Options**

### **Gemini Magnetic Phone Mount (or) XXL Phone Mount**

1. Utilizing the included 1/4-20 button head screw, place it through the open end of the Tibia Accessory Arm. Next, place the nylon washer over the screw and tighten onto the Vent Mount threaded tab.



To install either phone holder, loosen the collar on the holder and pop the ball on the mount into the socket, then re-tighten the collar.

2. **Gemini Magnetic Phone Mount:** Apply the included adhesive-backed, metal plate to the back of your phone or the inside of your phone protector case.



3. **XXL Phone Mount:**





## Accessory Gauge Pod

1. Place the included 1/4-20 Cap Head Screw through the mounting hole on the bottom of the Gauge Cup. Next, place the nylon washer over the screw then thread onto the mounting tab of the Vent Mount. Place the plastic cap into the screw mounting hole to finish off the installation of the gauge cup.



2. Install your gauge of choice and run the wires down alongside the gap in the adjustable steering column, into the dash, and down towards the fuse panel behind the drivers side kick panel. Finish your gauge install by following the instructions included with your particular brand of gauge.